



# Sleeve Sensor Installation Guide



1

Inspect Sleeve to ensure it is free of cuts, or defects.

Install the end gasket on the elbow, placement should be slightly above compression coupler. Ensure that the gasket is on the straight portion of the elbow.



2

Slide sleeve over top of elbow. Fitting should be on the inside radius of the elbow. Fit the sleeve overtop of the end gasket.



3

Install T bolt clamp over sleeve, ensuring clamp tightens on end gasket.



4

- Install the remaining end gasket sliding inside the sleeve.
- Install the remaining T bolt clamp over the sleeve.
- Attach the airline to the fitting and sensor box.

5

Top terminal on sensor is common, middle is normally open(NO) bottom is normally closed(NC)

